



TILLAGE POINTS

PRODUCT INFORMATION BULLETIN POINTS

Table of point weights (for transport)

PLAIN (UN-TIPPED) kg	PART NO.	DESCRIPTION	TUNGSTEN CARBIDE TIPPED kg
0.67	PR 1	4 ½" Combine	0.65
	PR 2-DB	4 ½" Deep blade, direct drill	1.13
0.76	PR 3	4" Combine, low profile	0.73
0.81	PR 4	5" Combine	0.82
0.97	PR 5	5" Horwood Bagshaw combine	0.95
1.30	PR 6	7" Connor Shea	1.33
0.66	PR 7	1 ½" Cultivator / ripper	0.66
1.33	PR 8	6" Cultivator, 44° stem angle	1.35
1.37	PR 9	7" Cultivator, 44° stem angle	1.38
	PR 9-DB	7" Deep blade cultivator	1.43
1.40	PR 10	8" Cultivator, 44° stem angle	1.37
1.35	PR 11	2 ½" Scarifier / ripper	1.34
1.54	PR 12	6" Scarifier buster	1.50
1.80	PR 13	7" Scarifier	1.77
2.02	PR 14	8" Scarifier low profile	1.99
1.36	PR 15	2 ½" Cultivator	1.41
2.22	PR 16	6" Cultivator (7/16" bolts)	2.22
2.22	PR 16-2	6" Cultivator (½" bolts)	2.22
2.34	PR 17	7 ½" Cultivator (7/16" bolts)	2.36
2.34	PR 17-2	7 ½" Cultivator (½" bolts)	2.36
2.20	PR 18	2 ½" Chisel plow	2.20
0.79	PR 19	2 ½" Knock-on tip	0.79
1.20	PR 20	6" Cultivator, 35° stem angle	1.19
1.25	PR 21	7" Cultivator, 35° stem angle	1.24
1.28	PR 22	8" Cultivator, 35° stem angle	1.24
0.59	PR 23	2" Cultivator / combine	0.59
2.30	PR 25	9" Scarifier, low profile	2.27
1.62	PR 26	2 ½" HB Stubblemaster ripper	1.59
3.23	PR 27	8" HB Stubblemaster scarifier	3.20

These weights may vary from time to time without notice and are intended as a guide only



TILLAGE POINTS

Table of product weights (for transport)

PART NO.	SPECIALISED NO-TILL POINTS	kg
	<u>MORRIS 'GUMBO'</u>	
PR 50	Knife point suit Morris 'Gumbo' system	1.52
PR 51	Deep Knife point " " " "	1.49
PR 53	Half wing plate " " " "	0.38
PR 54	Full 4" wing plate " " " "	0.47
PR 55	Full 5" wing plate " " " "	0.54
PR 57	Side plate LH or RH " " " "	0.18
	<u>CONCORD</u>	
PR 60	Knife point to suit Concord Anderson opener	1.20
PR 61	Knife point..... 20mm repl. for weld-on point	1.85
PR 63	Wedge plate to suit Concord Anderson opener	0.32
PR 64	Full wing plate " " " "	1.65
	<u>PRIMARY LOW-INVERSION TINE</u>	
PR UTS-P-1	Primary tine Ultra-T-Seeder	3.56
	<u>PRIMARY NICHOLS</u>	
NI P-3327-190	Super Seeder-190 mm Tungsten carbide	4.27
NI P-3327-150	Super Seeder-150 mm Tungsten carbide	4.19
NI P-3325-200	Knife point-200 mm Tungsten carbide	3.13
NI P-3325-150	Knife point-150 mm Tungsten carbide	3.10
NI P-3326-F	150 mm Super Seeder	2.18

PART No. prefix	<u>APPROXIMATE WEIGHTS OF SOME OTHER PRODUCTS</u>	kg
PCT-D, PCT-V	Primary Coil Tine, bare	9.50
P/ WHEEL Ass'y Std.	Press wheel ass'y complete, with 12" poly wheels	23
P/ WHEEL Ass'y H/duty	Press wheel ass'y complete, heavy duty	40
ST-DPB-F	Dual / deep banding boot for 32mm o/d hose	1.46
ST-DPB-LF	Deep banding boot for 38mm o/d hose	1.73
ST-LRB	Large rubber Flexi-boot for 38mm o/d hose	0.76
ST-RFB	Standard rubber Flexi boot for 32mm o/d hose	0.63
ST-SBB various	Single shoot bracket for 2-bolt culti's & c/plows	0.75
ST-SBEO various	Single shoot bracket for single bolt machines	0.56
ST-UNI	Fertiliser boot for some single bolt machines	0.84
TT-	Residue deflector (trash tube)	0.95
PCF-	Convert-a-drill , frame only	225



TILLAGE POINTS

Table of point weights (for transport)

PART NO.	ALL WITH TUNGSTEN CARBIDE (T. C.) WEAR PROTECTION	kg
PR 30-DB	8" Deep blade cultivator (7/16" bolts)	2.55
PR 30-2-DB	8" Deep blade cultivator (1/2" bolts)	2.58
PR 31-DB	6" Deep blade cultivator (7/16" bolts)	2.52
PR 31-2-DB	6" Deep blade cultivator (1/2" bolts)	2.55
PR 41	2 1/2" Chisel plow slip-on tip	0.96
PR 42	Spear point for use with PA42-1 adaptor, or on spear-point specific tines (i.e. H.Bagshaw & Gason)	0.46
PR 44	Slip-on Knife point 12mm (includes roll pin)	2.27
PR 45	Slip-on Super Seeder (includes roll pin)	2.47
PA-15554	"Slimline" wedge for 1/2" bolts @ 45mm centres	0.25
PA-15555	"Slimline" wedge for 7/16" bolts @ 45mm centres	0.25
PA-15557	"Slimline" wedge for 1/2" bolts @ 57mm centres	0.25
PR 84-DB	Scarifier Super Seeder (50mm wing)	2.52
PR 84-DB-TW	Scarifier Super Seeder (50mm T.C. wing)	2.60
PR 86-DB	Super Seeder, heavy duty (60mm wing)	2.49
PR 86-DB-TW	Super Seeder, heavy duty (60mm T.C. wing)	2.50
PR 86-DB-ATW	Super Seeder, heavy duty (angled T.C. wing)	2.51
PR 87	Knife point, 16mm, heavy duty (two x 1/2" bolts)	2.25
PR 90	Thomas tine point (no Tungsten Carbide)	0.34
PR 91	Knife point, 20mm (single bolt, 7/16")	0.92
PR 92M	Mini T - boot	0.65
PR 92M-TW	Mini T - boot (T.C. wing)	0.67
PR 93	Baker style T-boot	0.86
PR 93-TW	Baker style T-boot (T.C. wing)	0.88
PR 94	Super Seeder (50mm wing, single bolt 7/16")	1.23
PR 94-TW	Super Seeder (50mm T.C. wing)	1.27
PR 94-DB	Super Seeder (60mm wing deep blade, h / duty)	1.50
PR 94-DB-TW	Super Seeder (60mm, T.C. wing)	1.54
PR 95-DB	4 1/2" N- Jector Super Seeder for single bolt tines	1.73
PR 96-DB	Super Seeder (60mm wing, two x 7/16" bolts)	1.96
PR 96-DB-TW	Super Seeder (60mm T.C. wing)	2.03
PR 96-DB-ATW	Super Seeder (60mm angled T.C. wing)	2.03
PR 97	Knife point (two x 7/16" bolts)	1.90