

PRIMARY PRECISION SEEDER BAR

FLEXI BOOT OPTIONS and PART No's

<u>Rubber flexi-boot and</u> <u>mounting bracket</u> Popular 38mm seed boot for accurate placement and durability in most soils and conditions. Bracket provides height and angle-adjustability. Wear-protected steel sowing tail.

N.B. Must have delivery hose fully inserted into boot.



Fixed- angle Rubber flexi-boot and mounting bracket 38mm seed boot for accurate placement and durability in mostsoils and conditions. Angled bracket provides consistent. positioning of rubber boot. Can be used with or without spacer block to achieve ideal placement of seed in varying conditions. Wear-protected steel sowing tail. N.B. Must have delivery hose fully inserted into boot.

